

QuickFistClamps

One Piece Rubber Clamps

3" Quick Fist Installation Instructions



1. The two protrusions on the base will keep the clamp from turning while in use. Using the template below, drill 3 X 1/4" (6mm) holes. The outer two holes need be about 1/8" (3mm) deep. Use a M6 (1/4") bolt or screw and a washer to mount the QUICK FIST clamp.
2. The QUICK FIST can be mounted with the strap facing in any direction.
3. 3. To clamp: Put the Nozzle between the jaws and push the strap to reach the desired tightness.

TEMPLATE

