

# QuickFist Clamps

One Piece Rubber Clamps

## Go- Between Quick Fist Installation



1. Mount with two M6 (1/4") fine thread screws or bolts and washers (under the bolt or screwhead). Do not over-tighten, as the rubber just spreads.
2. The strap can be mounted with it facing in any direction.
3. To clamp: put a tool or implement into the jaws and push the strap to the desired tightness.